



大同強化磁器

餐館專用 DURABLE CHINA BREAK & CHIP RESISTANT



Customer's Pattern Logos Are Welcome



訂貨細節:

凡目錄上所示之花樣，皆適用於各類形式之餐具，再者，本公司之設計部門亦隨時竭誠為顧客之特殊圖案設計及燒字製造之樣式，力求完美符合客戶之需求，除了專屬設計花樣有最低訂購數量外，舉凡目錄上所示之產品，皆有一定安全存貨，使顧客能於不同價格下，對不同的產品做任意的訂購組合，已達本公司服務顧客至上之宗旨。

交貨期限:

樣品及訂單確認後三至六星期內交貨完畢。特殊設計之圖樣，交貨期事情況而定。

Order:

All items shown in catalogue are available instocks. Customer's special orders are also welcome but minimum quantity & price are subjected to quantity decoration and pattern.

Delivery:


Allow 3 to 6 weeks after confirmed sample/order for delivery except customer's special design.

燒字顏色參考色樣 Color Reference For Your Own logo


軸下彩 IN GLAZE	G1-1	G1-3	G1-5	G2-1	G2-3	G2-4	G3-1	G4-1	G5-1	G6-2	G7-1	G7-3
軸上彩 OVER GLAZE	R1-1	R1-4	R2-1	R2-4	R3-1	R4-1	R5-2	R6-2	R7-0	R7-1	R7-2	R8-1

印刷色樣與磁器顏色均有色差，正確顏色以產品為主。

中西式深·淺盤 Plate & Soup Plate




大圓盤 Round Serving Plate
P181 18"(45.5cm) P161 16"(41.5cm) P141 14"(36cm) P121 12"(30.5cm) P101 10"(26cm) P1291 9"(22.5cm) P1281 8"(20.5cm) P12H71 7.5"(18.9cm) P1271 7"(18cm) P12NH61 6.5"(16.5cm) P12H61 6.5"(16.5cm) P1261 6"(15cm)




圓盤/寬邊 Rimmed Round Plate
P70121 12"(32cm) P70111 11"(28cm) P111 10.5"(26.5cm) P13111 10"(25.5cm) P91 9"(24cm) P81 8"(20.5cm) P71 7"(17.5cm) P61 6"(15cm) P51 5"(12.5cm)



圓盤/寬邊 Rimmed Round Plate
P73H111 11.5"(29.2cm) P73111 10.5"(27.2cm) P7391 9"(23.5cm) P7381 8"(20.3cm) P7371 7"(18.5cm) P7361 6"(15.5cm)
圓盤 / Rimmed Round Plate
PB01 10"(24.5cm) P2291B 9.5"(24.5cm) PB91 9"(22.5cm)




圓湯盤 Soup Plate
P7392 9.5"(23.3cm) P92 9"(22.5cm) P82 8"(20cm) P72 7"(17.5cm) P62 6"(16cm) P4992 9"(23cm) P4982 8"(21cm)



長方盤 Square Plate
P24H133 12"(30cm)
四角盤 Square Plate
P24H113 12"(30 x 30cm)
三角盤 Triangle Plate
P24H123 12"(31 x 30.5cm)
球型淺沙拉盤 Salad Plate
P24H112 12"(30.5cm)
球型湯盤 Salad Plate
P24H104 10.5"(27.3cm)

大圓(深)盤 Serve Platter



大圓盤/寬邊 Rimmed Round Plate
PB32 16"(40.5cm) PB22 14"(36.6cm) PB12 12"(32cm)
圓淺湯盤 Soup Plate
P91142 14"(36cm) P91122 12"(32cm) P91112 11"(27.5cm)




圓深盤 Round Deep Plate
P13B62 16"(40.2cm) P13B42 14"(35.5cm) P13B12 12"(30cm)
圓盤 Rimmed Round Plate
PC32 16"(40.5cm)

長盤 Oval Platter



長盤/有邊 Rimmed Oval Plate
P183 18"(46.2cm) P58173 17"(43cm) P63 16"(41cm) P43 14"(35cm) P23 12"(31cm) P13 11"(28.5cm) P03 10"(25.5cm) P93 9"(23cm) P83 8"(20.5cm)



長盤 Oval Plate
P12183 18"(46.2cm) P1283 16"(42cm) P1243 14"(37cm) P1223 12"(31.5cm) P1203 10"(26cm) P1293 9"(24cm) P1283 8"(21cm)



七皇時盤組 7-Starter Serving Plate
P283-7pcs (38.8cm)
五果盤 Five Appetizer Server
P503 (32.2cm)
長船盤/有邊 Rimmed Oval Plate
P36H233 23.5"(60.5cm)

烤盤 · 小菜皿 Baking Plate & Dessert Plate



長方盤 Oblong Plate P2173 7"(18.2cm) 長方盤 Oblong Plate P7283 8"(21.2cm) 長方盤 Oblong Plate P74H83 8.5"(21cm) 長方盤 Oblong Plate P74H73 7.5"(19cm) 毛巾碟 Towel Dish P5053 5.5"(13.5cm) 毛巾碟 Towel Dish P2153 5"(13cm)



長方盤 Oblong Plate P9123 12"(30.5cm) 長方盤 Oblong Plate P9103 10"(26.2cm) 長方盤 Oblong Plate P9193 9"(23cm) 長方烤盤 Oblong Plate P56H73 7.5"(18.8cm) 長方烤盤 Oblong Plate P6373 7.25"(18.5cm)



長方烤盤 Oblong Plate A87H06 10.5"(26.8cm) 長方烤盤 Oblong Plate A87H99 9.5"(24.2cm) 長方烤盤 Oblong Plate P8673 (18.6cm) 長方烤盤 Oblong Plate P5163 (17cm)



湘式熱碗 Hunan Serving Soup Bowl P1394 9"(23.3cm) 橢圓深碗 Oval Deep Bowl P5604 10"(26.6cm) 橢圓烤盤 Oval Plate P8663 7.5"(19.5cm) 調味碟底碟 Saucer P0165S (23.5cm) 調味碟底碟 Saucer P7073 (18cm) 調味碟底碟 Saucer P5863 (18cm)



圓深湯盤 Round Deep Plate PB72 7"(18.5cm) 圓深湯盤 Round Deep Plate PB62 5.5"(16cm) 小菜盤 Round Deep Plate P52 4.5"(11.7cm) 圓湯盤 Soup Plate P5882 8"(19.6cm) 圓湯盤 Soup Plate P5872 6.5"(16.8cm) 水果盤 Fruit Plate P5852 5"(13.5cm)



水果碗 Fruit Bowl AB52 13.6cm 水果碗 Fruit Bowl P6852 14cm 沙拉碗 Salad Bowl P0472 18.8cm 沙拉碗 Salad Bowl P0462 14cm 反口醬油碟 Sauce Dish P1252 11.5cm 反口醬油碟 Sauce Dish P1242 10.4cm



小菜碟 Round Dish P1361 15.7cm 小菜碟 Round Dish PC51 12cm 小菜碟 Round Dish PC41 11.7cm 小菜碟 Round Dish PC31 11cm 貝殼盤 Shell Plate P70H73 17.8cm 貝殼盤 Shell Plate P7063 15.8cm 貝殼盤 Shell Plate P7053 13.8cm



烤盅 Ramekin P96H34 9.3 x H4.3cm / 150cc 烤盅 Ramekin P9634 8 x H4.2cm / 100cc 烤盅 Ramekin P96H24 6.4 x H3.7cm / 50cc 烤盅 Ramekin P7834 7.5 x H5cm 烤盅 Ramekin P78H24 7 x H4cm 鵝肝醬碟 Sauce Bowl P7334 7 x H4.8cm



沙拉碗 Octagon Soup Plate P7384 8"(20.4cm) 沙拉碗 Octagon Soup Plate P7374 7"(17.8cm) 沙拉碗 Octagon Soup Plate P7364 6"(14.8cm) 沙拉碗 Octagon Soup Plate P7354 5"(12.8cm) 卜羅 P7365 15 x H12cm / 1300cc 卜羅 P73H45 11 x H10cm / 550cc



煲盤 Octagon Stew Bowl P0324 11"(27cm) 煲盤 Octagon Stew Bowl P0304 10"(25cm) 煲盤 Octagon Stew Bowl P0394 9"(22.5cm) 煲盤 Octagon Stew Bowl P0384 8"(20.3cm) 煲盤 Octagon Stew Bowl P0474 7"(17.5cm)



圓烤盤 Round Dish P94B04 10"(25.9cm) 圓烤盤 Round Dish P94B94 9"(23.2cm) 圓烤盤 Round Dish P94B84 8"(20.8cm) 圓烤盤 Round Dish P94B74 7"(18cm)




生魚片盤 Sashimin Plate P8383 8.5"(21.5cm) 橢圓三格盤 Divided Plate P5683 9.5"(24.5cm) 龍蝦盤 Lobster Plate P8783 8"(20cm) 八角盤 Octagon Plate P5191 8.5"(22cm)

湯碗 · 飯碗 · 生意碗 Bowl



湯碗 Soup Bowl N8084 8"(20cm) / 1300cc
 湯碗 Soup Bowl N8074 7"(17.6cm) / 900cc
 湯碗 Soup Bowl N8064 6"(15cm) / 600cc
 湯麵碗 Noodle Soup Bowl P7074 7"(18.8cm) / 800cc
 湯麵碗 Noodle Soup Bowl P7064 6"(15.7cm) / 500cc



湯碗 Soup Bowl P1294 9"(23cm) / 1300cc
 湯碗 Soup Bowl P1264 8"(20cm) / 900cc
 湯碗 Soup Bowl P1274 7"(18cm) / 600cc
 湯碗 Soup Bowl P1264 6"(15.5cm) / 400cc



腰張碗 Soup Bowl P194 10.5"(27cm) / 2500cc
 腰張碗 Soup Bowl P184 9"(23.5cm) / 1700cc
 腰張碗 Soup Bowl P174 8"(21cm) / 1200cc
 湯碗 Soup Bowl P5094 9"(23.5cm) / 2300cc
 湯碗 Soup Bowl P5084 8"(20.3cm) / 1600cc
 湯碗 Soup Bowl P5074 7"(18cm) / 1000cc



反口飯碗 Rice Bowl P99 10.3cm
 港式飯碗 Rice Bowl P1289 11cm
 飯碗 Rice Bowl P7099 10.6cm
 飯碗 Rice Bowl A1389 12cm
 小湯碗 Small Soup Bowl P5859 10.2cm
 小湯碗 Small Soup Bowl P59 9.6cm
 港式小湯碗 Small Soup Bowl P1259 10cm
 港式魚翅碗 Shark Fin Bowl P1359 9.5cm



麵碗 Noodle Soup Bowl / w.Lid P69PL 15.9cm / 400cc
 湯碗 Soup Bowl A2069 15.4cm
 湯碗 Soup Bowl A1069 14cm
 湯碗 Soup Bowl P1269 13.9cm / 450cc
 湯碗 Soup Bowl P1064 15.8cm
 湯碗 Soup Bowl P2044 13.5cm / 330cc
 湯碗 Soup Bowl P2064 15.8cm

燉盅 · 湯盅 · 魚翅盅 Casserole & Special Bowl



大蓋碗附蓋 Casserole Bowl / w.Lid P0614PL 27cm / 2000cc
 大蓋碗附蓋 Casserole Bowl / w.Lid P0604PL 25cm / 1700cc
 大蓋碗附蓋 Casserole Bowl / w.Lid P0694PL 22.5cm / 1300cc
 大蓋碗附蓋 Casserole Bowl / w.Lid P0684PL 20cm / 1000cc
 大蓋碗附蓋 Casserole Bowl / w.Lid P1384PL 18.5cm / 650cc




富貴盅附蓋 Octogon Casserole / w.Lid P384PL 21.3cm / 2200cc
 富貴盅附蓋 Octogon Casserole / w.Lid P374PL 19cm / 1600cc
 富貴盅附蓋 Octogon Casserole / w.Lid P364PL 17.5cm / 1100cc
 富貴盅附蓋 Octogon Casserole / w.Lid P344PL 10.4cm / 350cc
 富貴盅附蓋 Octogon Casserole / w.Lid P334PL 10.5cm / 300cc
 富貴盅附蓋 Octogon Casserole / w.Lid P324PL 8.8cm / 180cc




如意盅附蓋 Round Casserole / w.Lid P1884PL 21cm / 1800cc
 如意盅附蓋 Round Casserole / w.Lid P1874PL 19.2cm / 1380cc
 如意盅附蓋 Round Casserole / w.Lid P1864PL 17.8cm / 1000cc
 如意盅附蓋 Round Casserole / w.Lid P1854PL 13.5cm / 600cc
 如意盅附蓋 Round Casserole / w.Lid P1844PL 11cm / 400cc



三件式魚翅盅 Sharks Fin Bowl / w. Saucer, Lid P6854PSL 12.3cm / 220cc 底碟 14.1cm
 三件式湯盅 Soup Bowl / w. Saucer, Lid P6854PSL 10.5cm / 200cc 底碟 14cm
 三件式魚翅盅 Sharks Fin Bowl / w. Saucer, Lid P1254PSL 12.3cm / 200cc 底碟 13.1cm
 三件式燕窩盅 Dessert Bowl / w. Saucer, Lid P5844PSL 9.2cm / 170cc 底碟 12.3cm
 三件式佛手盅 P5845PSL (8cm) 330cc 底碟(17.5cm)



三件式湯盅 Soup Bowl / w. Saucer, Lid A1354CSL 13.7cm / 290cc 底碟 15.2cm
 洋蔥碗附蓋 Soup Bowl / w.Lid 244PL 11.1cm / 320cc
 湯盅附蓋 Soup Bowl / w.Lid P7054PL 10.5cm / 280cc
 湯盅附蓋 Soup Bowl / w.Lid P5054PL 11cm / 210cc
 湯盅附蓋 Soup Bowl / w.Lid P5154PL 11.6cm / 210cc




湯盅 · 砂鍋 · 煙灰缸 Special Bowl/Casserole/Ash Tray



獅頭碗附蓋 P7465PL 10cm / 330cc
 獅頭碗 P7455 9.7cm / 300cc
 獅頭碗 P7445 9.3cm / 270cc
 小湯盅 P70H34 9.6 x H4.9cm / 130cc
 小湯盅 P74H34 9.6 x H4.9cm / 130cc
 湯碗 P5144 10.4cm
 花瓶 Vase P1305 H13.5cm
 花瓶 Vase P1405 H12cm



磁土鍋 Casserole P7395P 22.9 x H12.1cm / 2800cc
 高佛爐盅 Lion-Headed Soup Tureen P7485H 20 x H15cm / 2400cc
 佛跳牆 Steam Jar P7375P 16.5 x H16cm / 2200cc
 佛跳牆 Steam Jar P7385P 13.5 x H15cm / 3000cc
 佛跳牆附蓋 Steam Jar / w.Lid PF309PL 10 x H20cm / 2300cc
 佛跳牆附蓋 Steam Jar / w.Lid P7265PL 16 x H13cm / 1400cc



砂鍋 Casserole P805PL 12"(30.5cm)
 砂鍋 Casserole P604PL 11"(27.6cm)
 砂鍋 Casserole P803PL 10"(25cm)
 砂鍋 Casserole P802PL 8.5"(21.5cm)
 砂鍋 Casserole P801PL 7"(18.5cm)
 砂鍋 Casserole P800PL 6"(15.8cm)



煙灰缸 Ash Tray P597B 14 x H3.3cm
 煙灰缸(圓) Ash Tray P1058 12 x H2.8cm
 煙灰缸 Ash Tray P5058 8.9 x H3.3cm
 煙灰缸(圓) Ash Tray 1058E 12 x H2.8cm
 煙灰缸(方) Ash Tray P0158 9 x H3.7cm
 煙灰缸 Ash Tray C58 12.8 x H3.9cm
 煙灰缸 Ash Tray P7458 13 x H2.8cm
 煙灰缸 Ash Tray P7058 9.5 x H4cm
 煙灰缸(圓) Ash Tray P7358 8.6 x H3.3cm
 煙灰缸 Ash Tray P5858B 7.2 x H2.5cm



咖啡壺 · 茶壺 · 杯類 Coffee & Tea Pot/Cup



茶壺 Tea Pot P76PL 22cm / 800cc
 茶壺 Tea Pot P88PL 21cm / 700cc
 茶壺 Tea Pot P56PL 18.5cm / 600cc
 茶壺 Tea Pot A36PL 16.5cm / 360cc



茶壺 Tea Pot P1216PL 22cm / 850cc
 茶壺 Tea Pot P5806PL 19.5cm / 630cc
 茶壺 Tea Pot P16PL 23cm / 850cc
 茶壺 Tea Pot P06PL 20cm / 800cc



咖啡壺 Coffee Pot P7316PL 21cm / 780cc
 咖啡壺 Coffee Pot P7306PL 16cm / 380cc
 咖啡壺 Coffee Pot P0416PL 17cm / 650cc
 咖啡壺 Coffee Pot P0426PL 14cm / 330cc



茶壺 Tea Pot P8306PL 19cm / 550cc
 茶壺 Tea Pot P5206PL 17cm / 520cc
 暖壺座 Tea Warmer P72H55 13.3 x H6.7cm
 三件茶碗組 Chinese Tea Cup / w. Saucer, Lid P9110CSL 9.5cm / 180cc
 三件茶碗組 Chinese Tea Cup / w. Saucer, Lid P3100CSL 8.8cm / 150cc



茶杯 Tea Cup P449P 6.4cm / 140cc
 茶杯 Tea Cup P7039P 7.6cm / 125cc
 茶杯 Tea Cup P1249P 6.8cm / 130cc
 茶杯 Tea Cup P1229P 7.5cm / 130cc
 茶杯 Tea Cup P1239P 7.1cm / 100cc
 茶杯 Tea Cup N3059P 9cm / 160cc
 茶杯 Tea Cup P1649P 7.6cm / 150cc
 茶杯 Tea Cup P7239P 7.6cm / 140cc
 茶杯 Tea Cup R39P 7.3cm / 130cc

咖啡杯盤 · 馬克杯 Coffee Cup/Saucer & Mug




馬克杯 Mug N6490C 8.5 x H9cm / 330cc
 馬克杯 Mug N6090C 8 x H10cm / 310cc
 馬克杯 Mug N8290C 8 x H9.5cm / 310cc
 馬克杯 Mug N8270C 8.1 x H8.6cm / 270cc
 馬克杯 Mug N6990CL 7.8 x H9.3cm / 320cc



馬克杯 Mug N3590C 9 x H10.5cm / 480cc
 馬克杯 Mug N3580C 8.3 x H9.7cm / 380cc
 馬克杯 Mug P1890C 8.9 x H10.3cm / 400cc
 馬克杯 Mug N4890C 8 x H9.5cm / 280cc
 馬克杯 Mug N8090C 8.3 x H7.5cm / 270cc



寶咖啡杯 Coffee Cup P1260C 8cm / 190cc
 寶咖啡盤 Coffee Saucer P1260S 14.2cm
 純咖啡杯 Coffee Cup P0390C 8.5cm / 170cc
 純咖啡盤 Coffee Saucer P0390S 14.2cm
 雙耳湯碗 Soup Bowl / w. Handles P0490C 10.3cm / 250cc
 雙耳湯盤 Soup Saucer P0490S 14.7cm
 咖啡杯 Coffee Cup P1250C 7.5cm / 150cc
 咖啡盤 Coffee Saucer P1250S 13cm



紅茶杯 Tea Cup P7260C 9cm / 200cc
 紅茶杯底盤 Tea Saucer P7260S 14.7cm
 咖啡杯 Coffee Cup P8660C 7.3cm / 150cc
 咖啡盤 Coffee Saucer P8660S 13cm
 咖啡杯 Coffee Cup P0410C 6.5cm / 100cc
 咖啡盤 Coffee Saucer P0410S 13cm
 濃縮咖啡杯 Espresso Cup P0410C 6.5cm / 100cc
 濃縮咖啡杯底盤 Espresso Saucer P0410S 13cm




咖啡杯 Coffee Cup P7360C 8.5cm / 200cc
 咖啡杯底盤 Coffee Saucer P7360S 15cm
 濃縮咖啡杯 Espresso Cup P7310C 6.6cm / 100cc
 濃縮咖啡杯底盤 Espresso Saucer P7310S 12.1cm
 雙耳湯碗 Soup Bowl / w. Handles P7390C 14cm / 250cc
 雙耳湯盤 Soup Saucer P7390S 15cm
 馬克杯 Mug 90C 8.8 x H7cm / 250cc

桌面小品 Table Top Accessories




兩格味碟(圓) Sauce Dish P7441 9.9cm
 兩格味碟(圓) Sauce Dish P7241 9.9cm
 兩格味碟(圓) Sauce Dish P7041 9.9cm
 兩格味碟(方) Sauce Dish P0131 8.4cm
 味碟 Sauce Dish P1231 10cm
 味碟 Sauce Dish P21 8.8cm
 港式味碟 Sauce Dish P0121 7cm
 橢圓味碟 Oval Dish P7043 9.7cm
 沙拉碗 Salad Bowl P5634 9.2 x H3cm
 三角深碟 Triangle Bowl P24H34 9.8 x H4cm
 醬油碟 Sauce Dish A1734 9 x H3.7cm




大湯匙 Servins Spoon P0108 23.5cm
 湯匙 Spoon P0608 15.5cm
 湯匙 Spoon P3908 14cm
 甜湯匙 Spoon P7208 14.5cm
 日式湯匙 Spoon P7418 12.8cm
 咖啡匙 Spoon N0408 12.7cm
 湯匙 Spoon P08 14.3cm
 港式湯匙 Spoon P18 14cm
 小湯匙 Spoon P5818 12.8cm



湯筷架 Chopsticks & Spoon Rest P2238 11cm
 湯筷架 Chopsticks & Spoon Rest P5838 9.3cm
 湯筷架 Chopsticks & Spoon Rest P7038 9.5cm
 湯筷架 Chopsticks & Spoon Rest P5038 9.3cm
 湯匙座 Spoon Rest P838 8.8cm
 湯匙座 Spoon Rest P7238 7.6cm
 筷架 Chopsticks Rest P828 6cm
 筷架 Chopsticks Rest P828B 6cm



奶壺 Creamer P6002 11.5cm / 200cc
 奶壺 Creamer P602 9.2cm / 100cc
 奶壺/無耳 Creamer P6002A 8.1cm / 200cc
 奶壺/無耳 Creamer P602A 6.9cm / 100cc
 奶壺 Creamer P7425 12.5cm / 250cc
 奶壺 Creamer P7415 7cm / 50cc



糖罐附蓋 Sugar Jar / w.Lid P6003PL 9.3cm
 糖罐附蓋 Sugar Jar / w.Lid P6835PL 7.8cm
 糖包盅 Sugar Packer P7245 9.3cm
 糖包盅 Sugar Packer P9345 9.7cm
 牙籤盅 Toothpick Holder P2219P 3.4cm
 牙籤盅 Toothpick Holder P7068 4cm
 牙籤盅 Toothpick Holder P0168
 蛋杯 Egg Cup P9119P 6cm
 蛋杯 Egg Cup A0419P 4.5cm



胡椒罐 Pepper Shaker P0178H5 7cm
 鹽罐 Salt Shaker P0178H3 7cm
 胡椒罐 Pepper Shaker P7078H5 7.5cm
 鹽罐 Salt Shaker P7078H3 7.5cm
 醬醋瓶(圓) Soya Sauce & Vinegar Jar P0265PL H10.2cm / 110cc
 醬醋瓶(扁) Soya Sauce & Vinegar Jar P0185PL H10.2cm / 110cc
 調味碟附蓋 P7035PL 7.4cm
 辣椒罐附蓋 Hot Chili Sauce Pot P5835PL 5.7cm
 小湯匙 Sauce Spoon P5808 7cm
 牛排醬品 Sauce Sever P9115P 13cm / 150cc